



LTA110 INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

- Hydraulic jack and jack stands
- Wrench – 2x 18mm
- 3/8" Drive Ratchet, 18mm socket

INSTALLATION:

1. Lift the rear of the vehicle and safely support with jack stands under the cradle.
2. Remove wheel/tire to provide access to the work area.
3. Using two 18mm wrenches or a wrench and socket, remove the outer nut and bolt as shown in **IMAGE 1**.
4. Using the same tools, repeat the process for the inner. Remove factory trailing arm and set aside.
5. Install the BMR trailing arm using the original hardware and snug the bolts.
6. Torque the outer and inner bolts to 83 ft/lbs.
7. Using a grease gun, use 4-5 pumps to properly lubricate the poly bushing.
8. Re-install the wheel/tire and lower the vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.