



804-928-1839

www.tbamachine.com

[Email: todd@tbasuppressors.com](mailto:todd@tbasuppressors.com)

Thermo-Clocker Instructions for Hellcat Challenger, Charger, Demon, Redeye, Track Hawk

Tools Required

13mm wrench or socket

5 mm allen wrench

1. Drain the antifreeze and remove the hose from the thermostat housing. It will kink if you leave the hose attached once the thermos-clocker is installed. The hose needs to be loose so the hose can be repositioned properly and then remove your thermostat housing
2. Leave the thermostat in the original housing and bolt the thermo-clocker on top of it with the provided 5mm socket head tapered 8mm hardware.
3. Torque to 21 ft. lbs
4. Install the thermostat housing on to the thermo- clocker and install with the provided 13mm hex head hardware that was provided. The original bolts will not work, they are too long.
5. Torque to 21 ft. lbs
6. Attach the upper hose and clamp and refill your cooling system making sure to bleed the system so that there are no air pockets in the system. This will cause your car to overheat.